

## Appliances properties: Supra S.A. - Emeraude 1831 - Marke Supra

Master data	
Date of entry	Feb 26, 2008
Manufacturer	Supra S.A.
Model	Emeraude 1831
Product code	Marke Supra
Nominal heat output [kW]	10
Continuous burning appliance	_
ype test standard	DIN 18895
ear of testing	2000
Test laboratory	RWE Rheinbraun AG
Number of test laboratory	4.1
Number of test report	RB BF1-Hn 789
Flue gas values	
	Wood

12

300

12

Further important characteristics of the appliance

Suitability for installation to a shared flue 1)

Flue gas mass flow [g/s]

Flue gas mass flow [g/s]

Necessary flue draught [Pa]

Connectivity to the central heating system

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements\* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

<sup>1)</sup> For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

<sup>\*</sup> A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

## Norm: Inset appliances (with closed firedoor) D - 1.BImSchV According to the transitional rule §26 the appliance can be used until 31.12.2024 A - Austrian regulation referred to Art 15a B-VG CH - Swiss clean air act F - Crédit d'impôt à la transition énergétique

Evaluation of emission data and efficiency Wood

Evaluation of emission data and efficiency Lignite briquettes		
Norm : Inset appliances (with closed firedoor)	Evaluation	
O - 1.BImSchV	According to the transitional rule §26 the appliance can be used until 31.12.2024	
A - Austrian regulation referred to Art 15a B-VG	_	
CH - Swiss clean air act	ļ.	



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information