

Appliances properties: Supra S.A. - 162/162 VL - Marke Supra

Master data		
Date of entry	Feb 26, 2008	
Manufacturer	Supra S.A.	
Model	162/162 VL	
Product code	Marke Supra	
Nominal heat output [kW]	10	
Continuous burning appliance	_	
Type test standard	DIN 18895	
Year of testing	1995	
Test laboratory	RRF Rhein-Ruhr-Feuerstättenprüfstelle GmbH	
Number of test laboratory	2	
Number of test report	95 95 24 Z	
Flue gas values		
		Wood
Flue gas mass flow [g/s]		10
Flue gas mass flow [g/s]		230
Necessary flue draught [Pa]		12
Further important characteristics of the appliance		
Suitability for installation to a shared flue ¹⁾		-

Connectivity to the central heating system

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

¹⁾ For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

^{*} A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

Norm: Inset appliances (with closed firedoor) D - 1.BImSchV According to the transitional rule §26 the appliance can be used until 31.12.2024 A - Austrian regulation referred to Art 15a B-VG CH - Swiss clean air act F - Crédit d'impôt à la transition énergétique

Evaluation of emission data and efficiency Wood

Evaluation of emission data and efficiency Lignite briquettes		
Norm : Inset appliances (with closed firedoor)	Evaluation	
D - 1.BImSchV	According to the transitional rule §26 the appliance can be used until 31.12.2024	
A - Austrian regulation referred to Art 15a B-VG	_	
CH - Swiss clean air act	T	



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information