

## Appliances properties: Erwin Koppe keramische Heizgeräte GmbH - Gismo 5

Master data

Date of entry Apr 23, 2018

Manufacturer Erwin Koppe keramische Heizgeräte GmbH

Model Gismo 5

Nominal heat output [kW]

Continuous burning appliance

Type test standard DIN EN 13240

Year of testing 2011

Test laboratory RWE Rheinbraun AG

Number of test laboratory 4.1

Number of test report FSPS-Wa 2103-EN



Flue gas values

	Wood
Flue gas mass flow [g/s]	5.5
Flue gas mass flow [g/s]	285
Necessary flue draught [Pa]	12

Further important characteristics of the appliance

Suitability for installation to a shared flue<sup>1)</sup>



Connectivity to the central heating system

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements\* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

<sup>1)</sup> For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

<sup>\*</sup> A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

## Evaluation of emission data and efficiency Wood

Norm DIN EN 13240: Roomheater for wood logs	Evaluation
EU - Regulation (EU) 2015/1185 (Ecodesign)	<b>*</b>
D - 1.BlmSchV	Stufe 2
A - Austrian regulation referred to Art 15a B-VG	_
CH - Swiss clean air act	✓
DK - Danish regulation for air pollution from wood burners	✓
F - Crédit d'impôt à la transition énergétique	7☆
I - Italian Decree No. 186	**************************************

## Evaluation of emission data and efficiency Lignite briquettes

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing

D - 1.BImSchV



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information