

## Appliances properties: Max Blank GmbH - Sinnergie KE-1 gerade

Master data

Date of entryMay 21, 2010ManufacturerMax Blank GmbHModelSinnergie KE-1 gerade

Nominal heat output [kW] 7

Declared nominal space heating output [kW] 7

Continuous burning appliance

Type test standard DIN EN 13229

Year of testing 2009

Test laboratory Versuchs- und Forschungsanstalt der Hafner Österreichs

Number of test laboratory 8

Number of test report VFH-09-015-P



Flue gas values

	Wood	
Flue gas mass flow [g/s]	15	
Flue gas mass flow [g/s]	206	
Necessary flue draught [Pa]	11	

Further important characteristics of the appliance

Suitability for installation to a shared flue 1)



Connectivity to the central heating system



<sup>1)</sup> For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements\* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

<sup>\*</sup>A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

## Evaluation of emission data and efficiency Wood Norm : Inset appliances (with closed firedoor)

Norm : Inset appliances (with closed firedoor)	Evaluation
D - 1.BlmSchV	Stufe 1 Grandfathering
A - Austrian regulation referred to Art 15a B-VG	✓
CH - Swiss clean air act	✓
DK - Danish regulation for air pollution from wood burners	_
F - Crédit d'impôt à la transition énergétique	<b>∳</b> 6 <b>☆</b>

## Evaluation of emission data and efficiency Lignite briquettes

Norm : Inset appliances (with closed firedoor)

Evaluation

D - 1.BImSchV

According to the transitional rule §26 the appliance can be used until 31.12.2024



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information