

Appliances properties: Attika Feuer AG - Caro 130

Master data

Date of entryOct 17, 2023ManufacturerAttika Feuer AGModelCaro 130Nominal heat output [kW]5.5Declared nominal space heating output [kW]5

Continuous burning appliance

Type test standard DIN EN 13240

Year of testing 2023

Test laboratory Danish Technological Institute

Number of test laboratory

Number of test report 300-ELAB-2543-EN



Flue gas values

| | Wood |
|-----------------------------|------|
| Flue gas mass flow [g/s] | 4.3 |
| Flue gas mass flow [g/s] | 286 |
| Necessary flue draught [Pa] | 13 |

Further important characteristics of the appliance

Suitability for installation to a shared flue¹⁾



Connectivity to the central heating system



¹⁾ For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

* A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

Evaluation of emission data and efficiency Wood

| Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing | Evaluation |
|---|------------------------|
| D - 1.BlmSchV | Stufe 2 |
| A - Austrian regulation referred to Art 15a B-VG | ✓ |
| CH - Swiss clean air act | ✓ |
| DK - Danish regulation for air pollution from wood burners | ✓ |
| F - Crédit d'impôt à la transition énergétique | √ 7 ☆ |
| I - Italian Decree No. 186 | *** |

Evaluation of emission data and efficiency Lignite briquettes

| Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing | Evaluation |
|---|------------|
| D - 1.BlmSchV | I |



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information