

Number of test laboratory Number of test report

Appliances properties: ROKOSSA Energietechnik GmbH - IG1

Master data	
Date of entry	Mar 24, 2015
Manufacturer	ROKOSSA Energietechnik GmbH
Model	IG1
Nominal heat output [kW]	7.9
Declared nominal space heating output [kW]	2
Nominal water heating output [kW]	5
Water operating pressure [bar]	3
Continuous burning appliance	_
Type test standard	DIN EN 13240
Year of testing	2011
Test laboratory	RRF Rhein-Ruhr-Feuerstättenprüfstelle GmbH

Flue gas values	
	Wood
lue gas mass flow [g/s]	6.2
lue gas mass flow [g/s]	250
Necessary flue draught [Pa]	12

RRF-40 11 2831

Further important characteristics of the appliance



Connectivity to the central heating system

Suitability for installation to a shared flue¹⁾



General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

¹⁾ For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

^{*}A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

Evaluation of emission data and efficiency Wood

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing	Evaluation	
D - 1.BlmSchV	Stufe 2	
A - Austrian regulation referred to Art 15a B-VG	2015	
CH - Swiss clean air act	✓	
DK - Danish regulation for air pollution from wood burners	✓	
F - Crédit d'impôt à la transition énergétique	7☆	

Evaluation of emission data and efficiency Lignite briquettes

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing	Evaluation
D - 1.BlmSchV	



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information