

## Appliances properties: Spartherm Feuerungstechnik GmbH - Loftline Speedy MDRh

Master data Date of entry Nov 26, 2011 Spartherm Feuerungstechnik GmbH Manufacturer Model Loftline Speedy MDRh Nominal heat output [kW] Continuous burning appliance Type test standard DIN 18891 2005 Year of testing **Test laboratory** RRF Rhein-Ruhr-Feuerstättenprüfstelle GmbH Number of test laboratory Number of test report RRF-91 05 707 Flue gas values Wood Flue gas mass flow [g/s] 8.8 Flue gas mass flow [g/s] 310 Necessary flue draught [Pa] 12 Further important characteristics of the appliance Suitability for installation to a shared flue<sup>1)</sup> Connectivity to the central heating system

General technical approval for room sealed operation

On behalf of the manufacturer, the HKI Industrieverband e.V. hereby confirms compliance with the respective requirements\* in accordance with 1.BImSchV. The type test report of the fireplace has been submitted to the HKI Industrieverband e.V.

<sup>1)</sup> For unsealed operation it is possible to install the appliances to a shared flue system (please see installation manual).

<sup>\*</sup> A green check mark with a "1" indicates that the requirements of the 1st BImSchV are fulfilled, a green check mark with a "2" indicates that the 2nd level of the 1st BImSchV is fulfilled. A yellow check mark shows that the transitional regulation of the 1st BImSchV is fulfilled and a red line means that the 1st BImSchV is not fulfilled.

## Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing D - 1.BImSchV According to the transitional rule §26 the appliance can be used until 31.12.2024 A - Austrian regulation referred to Art 15a B-VG CH - Swiss clean air act DK - Danish regulation for air pollution from wood burners

## Evaluation of emission data and efficiency Lignite briquettes

F - Crédit d'impôt à la transition énergétique

Evaluation of emission data and efficiency Wood

Norm DIN EN 13240 (Intermittent burning): Roomheater with flat-layer firing

Evaluation

D - 1.BlmSchV

According to the transitional rule §26 the appliance can be used until \$31.12.2024



No symbol means that there are no requirements.

No measuring values are available for this fuel, operation with this fuel is not permitted

Here you will find further information